

Mail Server Details

Main SMTP Server: mail.tpg.com.au

Login: Your TPG email address

Password: Your password

Port: 25

Authentication: None

TPG requires DNS entries to be added also. They use a primary and secondary server Australia wide On your MFD these will generally be found under Network Settings then TCPIP

TPG DNS Server

Primary DNS: 203.12.160.35

Secondary DNS: 203.12.160.36

Creator: EID Technical Page 1 of 7 Date: 8 Mar 2020


Setup on the MFD Web Interface

Desktop Series 1

1. Input your printers TCPIP address into your web browser



Go to Settings > Network Port > SMTP Setup



- 3. Input your smtp details and hit submit
- 4. Next go to Settings > Network Port > TCPIP

DNS Server Address	203	. 12	. 160	. 35	If DHCP or BOOTP is not on the network
Backup DNS Server Address	203	. 12	. 160	. 36	
Backup DNS Server Address 2	192	. 168	. 0	. 1	
Backup DNS Server Address 3	0	. 0	. 0	. 0	


- 5. Scroll down to the DNS server address and input your DNS entries
- 6. Press "Submit"

Desktop Series 2

1. Input your printers TCPIP address into your web browser




2. Go to Settings > Email Setup



3. Input your SMTP Details and press "Save"

4. Next click on Network Ports > TCPIP




5. Input DNS entries then press "Save"


Creator: EID Technical Page **5** of **7** Date: 8 Mar 2020

EBN and EBX using TopAccess

1. Input your printers TCPIP address into your web browser



- 1. Login with User name (admin) and Password (123456)
- 2. Then click on Administration > Network > SMTP Client




- 3. Input your SMTP details.
- 4. Press "Save"
- 5. Click on "Network"



6. Click on "DNS"

7. Input your DNS entries for Telstra based on your state



- 8. Scroll to the bottom and press "Save"
- 9. You also need to set a valid send from address, Administration > Setup > Email



- 10. Input a valid email account here.
- 11. Press "Save"