

## TOSHIBA e-STUDIO™ MULTIFUNCTION PRINTER (MFP) CLEANING GUIDE

Toshiba e-STUDIO MFPs are designed for use in the most demanding office environments.

Since Toshiba MFPs are often shared by a multitude of users and touching the user interface and other parts of the device are common in normal use, Toshiba has developed the following guidelines for cleaning the exterior surfaces of e-STUDIO MFPs:

1. Use a soft cloth and alcohol for disinfection (ethanol).
2. Be sure to turn the power off before cleaning in order to avoid malfunction.\*
3. Do not directly spray alcohol on the MFP. Dampen a soft cloth and then gently wipe the MFP.
4. Areas recommended for cleaning:
  - Control panel (LCD, buttons, keys, etc.)
  - Platen cover or covers in the Document Feeder
  - Side guides in the Document Feeder
  - Jam access cover
  - Side guides in the bypass tray

### RECOMMENDED CLEANING SOLUTION:



Ethanol

### FREQUENCY:



Clean as often as needed without affecting the longevity or quality of the equipment

### ADDITIONAL RECOMMENDATION:



pCAP-compatible stylus is an alternative option to touch

For more information on COVID-19, please visit [www.health.gov.au/news/health-alerts/novel-coronavirus-2019-ncov-health-alert](http://www.health.gov.au/news/health-alerts/novel-coronavirus-2019-ncov-health-alert)

## TOP DO'S



Be sure to turn the power off before cleaning in order to avoid malfunction\*



Use a microfibre cleaning cloth or soft towels



Spray the cleaner onto the cleaning cloth/towel and then wipe the surface to be cleaned



Clean with a cloth/towel that is damp but not soaked/dripping wet



Consult trained service personnel for cleaning of the interior of electronic equipment

## TOP DON'TS



Do not spray cleaners directly onto equipment



Do not use abrasive cleaners (powders) or abrasive cleaning materials (scrub brush, scouring pad, etc.)



Do not soak the electronic equipment with cleaning liquid



Never attempt to clean the following portions with alcohol: original glass, scanning area (surface of the long rectangular glass)

\*Refer to your device manual for proper instructions before shutting down your device.